

## Installation Guide - ARES

- ◆ Remove firebricks from cavity
- ◆ Seal the gap between the cavity and the fascia with FEI batts or mortar and cement or both
- ◆ Fit flues together (3 rivets in each and seal with manisealor fire cement) lower down chimney support at top
- ◆ Fit offset if required
- ◆ Place firebox in cavity, level and centre
- ◆ Fit starter shroud into outer spigot of fire
- ◆ Fit flue to firebox, seal and attach to flue spigot with stainless steel rivet or stainless steel screw (ensure flue is centred in chimney)
- ◆ Fit 2 x 1200 8" shrouds if possible (not supplied)
- ◆ Fit earthquake restraints to firebox
- ◆ Fit FEI batts around firebox casing. (Do not cover air intake spigot)
- ◆ Seal tightly with batts between firebox casing and fireplace fascia opening
- ◆ Fit Ethos fascia, top and bottom grills
- ◆ Check the door and air control is working correctly
- ◆ Arrange inspection from your building authority if required